

Sterling



Installation, commissioning
and user manual



3 kW Electric
High Level Fan Heater

Contents

Introduction	2
Declaration of conformity	3
Symbols used in this guide	4
Important safety and installation instructions	4
Product dimensions	6
Product performance	6
Protection	6
Mounting	6
Installation	7
Electrical Connection	8
Controller	8
To replace the fan heater assembly	8
If your heater does not work	8
HPPS01 - Wireless Controller - Quick set up	9
Operation	10
Heat Control	10
Maintenance	10
Controller - Introduction	11
Installation & User Manual - Controller	13
Registering your product	23
Disposal	23
After sales	23

Introduction

In the event of items missing or visible damage please contact us on 01245 324560.

The STR3EL is a quiet High Level Fan Heater designed for Commercial and Industrial situations. It is suitable for wall mounting. The Heater incorporates a tangential flow fan and the unit is designed to operate in free air conditions. It is important that there should be no restriction to the free flow of air through the unit.

Warning

- Do NOT site the appliance in a corner.
- Do NOT handle the appliance with wet hands.
- Do NOT use the appliance in workshops or rooms where excessive dust is generated or present.
- Ensure that nothing is pushed into any aperture of this appliance.
- Do NOT touch outlet grille when the appliance is in use.
- Do NOT cover or restrict any aperture of the appliance when in use.
- Do NOT use the appliance if damaged.
- Do NOT leave the appliance unattended where young children are present.

Declaration of conformity

In accordance with UK Government Guidance.

We hereby certify that the appliances detailed hereon have been inspected and tested, and conform to the requirements of the following uk statutory instruments:

Electrical Equipment (Safety) Regulations
2016 SI. 2016 1101
Electromagnetic Compatibility Regulations
2016 SI. 2016 No. 1091
Radio Equipment Regulations 2017 SI. 2017
No. 1206
The Ecodesign for Energy Related Products
and Energy Information (Amendment)
(EU Exit)
Regulations 2019. SI. 2010 2617
The Restriction of use of Certain Hazardous
Substances. SI. 2012 No. 3032

Transposed standards used:

BSEN55014 (2006)
BSEN301 489.1 & .3
BSEN300 220.1 & .2
BSEN60 730.2.9
BSEN 60.335.1 (2012) BS EN 60.335.2.30 (2009)

Customer: Smiths Environmental Products Ltd.

Part number and description of appliance:
STR3E 3kW High Level Fan Heater 240V 50HZ

Name of responsible person: A C Reynolds

Position: Quality Engineering

Date: 15/03/21

Consort Equipment Products Ltd.
Thornton Industrial Estate,
Milford Haven,
Pembrokeshire, SA73 2RT. UK
Tel: +44 1646 692132

Symbols

This manual contains information and prescriptions marked by the following symbols:



Ignoring these safety provisions marked by the symbol "caution: hazard" may endanger the safety of people.



Ignoring these safety provisions marked by the symbol "caution: electricity" may endanger the safety of people, as well as the integrity of the equipment.



High temperature surface. Take utmost care to prevent people from getting in contact with the hot surfaces of the appliance.



To avoid overheating, the appliance should not be draped with clothing or other material.

Important safety and installation instructions

Prior to installation, read these installation and operating instructions. The installation and operation should also be in accordance with national regulations and accepted codes of good practice.



This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision. Children aged from 3 years and less than 8 years shall only switch on/off the appliance provided that it has been placed or installed in its intended normal operating position and they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children aged from 3 years and less than 8 years shall not plug in, regulate and clean the appliance or perform user maintenance.

To guard against injury, basic safety precautions should be observed, including the following:

1. Read and follow all safety instructions and all the important notices on the appliance before installing, using and maintaining the appliance. Failure to do so may cause personal injury or damage to the appliance or installation.
2. Always disconnect electrical supply before putting on or taking off parts and whilst the equipment is being installed, maintained or handled. Never work with bare feet and/or with wet hands.
3. Carefully examine the appliance before and after installation. Do not operate the appliance if it has a damaged supply cord or enclosure, or if it is malfunctioning or it is dropped or damaged in any manner. Inspect the appliance periodically.
4. Improper use.
Do not use this appliance:
 - In locations where special conditions prevail, such as the presence of a corrosive or explosive atmosphere (dust, vapour or gas) (EN60335-2-51);
 - For other than intended use.
5. **CAUTION**
Some parts of this product can become very hot and cause burns. Particular attention has to be given where children and vulnerable people are present.
6. Installation.
The appliance must be mounted in a stable/fixed position in a dry, well ventilated, frost-free, waterproof and protected place, with sufficient ventilation around it. Make sure that the appliance is securely and correctly installed before operating it and that there is enough room around it for maintenance operations, dismantling, checking for free inspection.



The maximum ambient temperature at which the appliance is to be used is 40°C (EN60335-2-51).

7. Electrical connection

IMPORTANT: Connection to the power supply is by means of a power cable which can be fitted with a plug-type connection or a two pole isolating switch with a minimum contact opening of 3 mm.

Electrical connection must be carried out by a qualified electrician and in accordance with local regulations and both data on the name-plate and the appropriate diagram inside the terminal box cover.

Follow all safety standards.

8. Connect the appliance only to a mains supply protected by a Residual Current Device (RCD or Ground-Fault Circuit-Interrupter) with a rated residual operating current not exceeding 30mA.

9. Prior to any modification being made to the equipment, it must be agreed with and authorised by the manufacturer. Original spare parts and accessories authorised by the manufacturer are integral part contributing to the safety of the equipment and of the machines. The use of non original components or accessories may endanger the safety and causes the termination of the warranty. Safe operation is only assured for the applications and conditions described in Application of this manual.

10. In order to avoid overheating, do not cover the equipment.




Non-observance of the safety instructions results in the loss of any claims to damages.


The indicated limit values are binding and cannot be exceeded for any reason whatsoever.

KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE.

Product dimensions



HHPS01
Wireless
Controller



Product performance

Heat output

Heat Output (kW)	Fused spur	Total Power Consumption (kW)	Sound Levels (dBA)	Casting colour	Fan-only
1kW/2kW/3kW	13A	1kW/2kW/3kW	39	white	•

Sound levels measured at 1.5m with the product installed at 2.2m high

Protection

The unit is protected in the event of fan failure, or an obstruction of the free airflow, by a single thermal PTC Self Hold Cut-out. Having tripped, the PTC Cut-out remains open, effectively switching off the heating elements as long as mains power is available inside the appliance. The PTC Cut-out will only reset when the appliance is switched OFF and allowed to cool for at least 20 minutes.

Mounting

The unit should be positioned so that the air flow is not obstructed.

The normal mounting height is 2.3m above the floor, although this will depend to some extent on the situation. The unit should be mounted at least 200mm below ceiling. The heater can be arranged to blow air at any angle, from horizontal to vertically downwards, subject to the conditions mentioned below. It is suggested that an angle of 45 deg is a convenient starting point when setting

up the unit. It must always be installed with the axis of the motor horizontal. Failure to ensure this will result in excessive bearing wear and premature failure.

A mounting bracket is provided for mounting to a wall.

The heater should not be mounted in situations where it may be subject to conditions of excessive humidity or the atmosphere is corrosive.

Installation

IN ALL CASES, THE UNIT SHOULD BE WIRED IN ACCORDANCE WITH IET REGULATIONS FOR THE ELECTRICAL EQUIPMENT OF BUILDINGS.





Loosen mounting screws, allowing the mounting bracket to be removed from the unit. Making sure that the mounting bracket is horizontal fix the bracket to the wall using appropriate screws.

Looking directly at the output grille the top cover is secured by 2 screws which are located at the upper left and upper right of the outlet grille. Once the 2 screws are removed the curved top

cover can now be removed by lifting it off the two slot hinges located at the opposite side to the 2 screws/ output grille.

Place the unit on the mounting bracket ensuring the washers are spaced as on the diagram.

Tighten screws to hold the unit at the required angle.



Electrical Connection

This unit is suitable for connection to a 230/240V 50Hz single phase AC supply. The maximum load / output of the heater is 3kW. Connection to the mains supply should be via a switched fused isolator.

To connect a supply to the heater the curved top cover first needs to be removed. Looking directly at the output grille the top cover is secured by two screws which are located at the upper left and right of the outlet grille. Once the 2 screws are removed the curved top cover can be removed by lifting it up and away from the output grille, then lifting off the cover from the two slot hinges located at the opposite side to the two screws/ output grille. The input terminal block, marked ENL, is fitted at the left-hand side of the unit looking from above (at the opposite end to the fan motor).

To the unit connect a suitable length of 3 core 1.5 mm² flexible cable to the input terminal block marked ENL.

For safety reasons, a sound earth connection MUST ALWAYS be made to the unit before being used.

Refit the heater front cover.

Controller

The unit is supplied with a HHPS01 Wireless controller. This controller must be used in conjunction with the heater.

Important: The heater will not function without the controller.

The controller should be positioned 1.5m above the floor and in the same room as the heater. The controller should be fixed to the wall. Avoid areas with draft or direct sun. Do not position the controller above or close to the heater or other heat sources. Damp areas or areas where the controller can be mechanically damaged should also be avoided. Avoid installing the controller in areas where there are metal objects between the heater and the controller. This will reduce the RF range. The RF range in ideal conditions can be up to 20m however this can be reduced when the signal is passing through the walls or other objects. The range can be also affected where the controller is mounted close to power cables, motors or equipment producing strong

electromagnetic field. If the temperature control feature is used it is necessary to use one controller for each room or zone.

To reset the PTC self hold cut-out

DO NOT ADJUST BY HAND ANY INTERNAL COMPONENTS

- a) The cut-out is reset by switching OFF mains power to the appliance.
- b) Allow the appliance to cool for 20 minutes
- c) Reconnect mains power, switch ON the appliance.
- d) If the cut-out trips again the appliance and installation should be checked by a qualified electrician.

If your heater does not work

- Check that the unit is wired correctly
- Check that the fuse has not blown in the connection to the unit
- Check re-set of PTC (as described under relevant section)
- Check the controller is calling for heat.
- Check the unit is paired with the controller
- Check the battery condition in the controller and replace if necessary


Do NOT attempt to repair the heater yourself

Should none of the above remedies work, disconnect heater from power supply and consult accredited service agent. If the appliance is still under guarantee, return it to your supplier.

HHPS01 Wireless Controller – Quick Set Up

1. Ensure the heater is installed and connected to the mains power supply.

DO NOT TURN THE MAINS POWER ON AT THE WALL UNTIL ASKED IN THE INSTRUCTIONS BELOW.




2. Unpackage the controller and install the batteries. Use a small Phillips screwdriver to release the controller from the bracket. The screen should now show the current room temperature.



3. Set the heater fan switch to **ON**. Switch on the power at the wall and **within 20 seconds** simultaneously press and hold the **PROG** and **MODE** buttons on the controller until the screen shows **PAIR**.

The controller will revert to showing room temperature and the heater unit will run. With water-based heating systems, if the central heating system is not turned on and the water temperature is cool then the unit will switch off after four seconds. Electric heaters will continue to run if the demand temperature is higher than the ambient room temperature.



Note: Failure to switch on the power and initiate pairing within 20 seconds will result in the heater and controller not being paired and the heater unit should be switched off at the wall and the pairing process should be restarted from Step 3.

4. The controller can be set into one of four modes – **BOOST**, **MANUAL**, **FROST PROTECT** and **AUTO**.

To cycle through the four modes press the **MODE** button so the screen backlight illuminates, then repeatedly press the **MODE** button until the required mode is shown on the screen.

If the **MODE** button is not pressed quickly enough then the controller will drop into the last mode that was selected as you were pressing the button and the next time you opt to change modes it will start again at the beginning of the list. Full details of each mode can be found in the controller manual.





5. To set the required thermostat temperature press the **TEMP** button to bring up the adjustment icon on the screen. Use the + and - buttons to select the required temperature. The radiator symbol will appear when heating is demanded.
6. On electric fan heaters, set the heat output switches on the front of the heater to the desired position.



7. To turn off the heating, press the **POWER** button in the centre of the controller (DO NOT HOLD THE BUTTON IN) to go into **STANDBY**. Pressing the power button again will switch the heating back on into the last mode that was selected, and with the last room temperature that was set.

Operation

The lower right-hand switch connects the mains supply to the fan motor (giving cold air flow) and energizes the heat control switches.

Note: wireless controller must be in the on position for the heater to work.

Heat Control

When the centre switch (marked with 1 bar) is depressed the output is 1kW.

When top switch (marked with 2 bars) is depressed the heat output is 2kW.

When both switches are depressed the heat output is 3kW.

Note: for all heat settings the lower right-hand must be set to on (fan).

Maintenance

ALWAYS ENSURE THAT THE MAIN EXTERNAL ELECTRICITY SUPPLY IS SWITCHED OFF BEFORE ATTENDING TO THE SERVICING OF THE UNIT.

To obtain the best results from the Heater it is necessary to avoid any buildup of dust or dirt within the unit or on the air inlet grille. For this reason the unit should be cleaned regularly, paying particular attention to the removal of dirt build-up on the back of the fan rotor blades.

The removal of dust and dirt is best achieved using a soft brush.

Advanced setup options are described fully in the Controller User Manual at the end of this document (page 13).

Controller - Introduction

In compliance with LOT20 European legislation, this product is supplied with a wireless battery powered wall-mounted time and temperature controller. The product will NOT function without the wall-mounted controller. The controller can control an unlimited number of heaters.

The controller is primarily designed to minimise energy wastage and ensure the room is maintained at the comfort level set by the user. In the basic setting, the controller is a simple room thermostat in which the heater will run until the set temperature is reached. If the room temperatures falls the heater will switch on again until the set temperature is reached.

The operating range is between 15°C and 35°C.

The controller has a number of advanced features that, if required MUST be set during the installation process. Please discuss with your customer which features they require.

- **Programmable Timer**

To allocate designated time slots in which the room will be heated.

- **Frost Protection**

Can be used in situations where you require a minimum room temperature to be maintained, between 4-15 degrees C.

- **Maximum Temperature Setting**

This can be set to limit the maximum temperature set by the user.

- **Open Window Detect**

Will switch off the heating to limit the loss of energy when it detects a sudden temperature drop as a result of an open window or door, switching back on when it detects it has been closed again.



Batteries in Wall Controller

Is recommended that the batteries are changed every 12 months to protect potential damage by batteries leaking (batteries are supplied with the controller).

You do not need to re-pair after batteries have been changed (pairing is done by programming the chip memory).


Wireless Controller Self Diagnostic

The controller is equipped with a self diagnostic software that will check functionality of all main components. If there is a fault with any part of the controller or controller is operating outside of the temperature limits, the display will show 'Err' on the display. If this happens, controller will not function in order to protect itself and the heaters.

Notes

HHPS01 Controller

Installation and control
user manual



HHPS01
WIRELESS CONTROLLER

Contents

Introduction	14
Declaration of conformity	15
Product dimensions	15
Pairing the heater to the HHPS01	16
Basic Operation	16
Boost mode	17
Manual temperature mode	17
Frost protection mode	17
Auto mode	17
Heat Symbol	17
Keys locking	18
Open Window Detection	18
Displaying the time/temperature	18
Setting the automatic program schedule	19
Automatic program overview	20
Basic Overview	20
Set program inactive	20
Copy day function	20
Setup menu	21
Choosing a position in a room	22
Installing the controller	22
Batteries	22
Registering your product	23
Disposal	23
After sales and spares	23

Introduction

In the event of items missing or visible damage please contact us on 01245 324560.

Keep the batteries out of reach of children

- Do NOT use if the battery compartment is not secure
- Dispose of used batteries correctly and safely
- Operating temperature range -10 to +40°C.

Please note the guarantee may be invalidated if this product is not installed and used in accordance with this guide.

Declaration of conformity

In accordance with UK Government Guidance.

THE APPLIANCES DETAILED HEREON HAVE BEEN
INSPECTED AND TESTED, AND CONFORM TO
THE REQUIREMENTS OF THE FOLLOWING UK
STATUTORY INSTRUMENTS WHERE APPLICABLE:

Electrical Equipment (Safety) Regulations 2016
SI. 2016 1101

Electromagnetic Compatibility Regulations 2016
SI. 2016 No. 1091

Radio Equipment Regulations 2017
SI. 2017 No. 1206

The Ecodesign for Energy Related Products
and Energy Information (Amendment) (EU Exit)
Regulations 2019. SI. 2010 2617

The Restriction of use of Certain Hazardous
Substances. SI. 2012 No. 3032

The Waste Electrical and Electronic Equipment
Regulations 2013. SI. 2013 No. 3113

Transposed standards used:

BSEN55014 (2006)

BSEN301 489.1 & .3


BSEN300 220.1 & .2

BSEN60730.2.9

BSEN60335.1(2012)

BSEN60335.2.30 (2009)

Product dimensions



Overview

The HHPS01 wireless controller can control an unlimited number products provided they are within range. To do this, the controller must be paired with each heater. **The heater will not operate until it has been paired to the controller.**

Pairing the heater to the HHPS01

In order to pair your appliance with the controller you must:

- Ensure power to the appliance is OFF.
- Set the heater fan switch to ON.
- Turn the power to the appliance ON.
- Within 20 seconds, press and hold the PROG and MODE buttons on the controller until the display shows 'PAIR'
- The fan should run and the appliance ready to be used.


Basic operation

The HHPS01 also has a **STANDBY MODE**. To enter/exit this mode, press the standby button. In **STANDBY MODE**, the heating will not be activated and the display will be blank.

The HHPS01 has 4 standard operating modes: **BOOST, MANUAL, FROST PROTECT and AUTO**. Each mode can be selected by pressing the MODE button to cycle through the options. The cycle sequence will always start with **BOOST** mode followed by **MANUAL, FROST PROTECTION** and **AUTO**.

The HHPS01 also has two special operating modes. These are **MANUAL CONTROL MODE** and **LOCAL TEMPERATURE CONTROL MODE**. These are accessed via setup menu.

To adjust the operating mode/settings of the HHPS01, the display must first be activated. If the controller is in **STANDBY MODE**, press the power button. The controller will exit standby mode and the display will be activated for 10 seconds. If the controller is not in **STANDBY MODE**, press any of the TIME, TEMP or MODE buttons once. The display will be activated for 10 seconds.



Boost mode

The boost feature increases the room temperature for 15 minutes.

To amend the set temperature when in **BOOST** mode, activate the display and then press TEMP. Next, use the + and - buttons to change the temperature. Once the temperature is set, you can leave the display to return to the main screen and the settings will be saved. After 15 minutes, the HHPS01 will return to the previous operating mode.

Whilst in boost mode, activate the display and press the PROG button to increase the boost period. The boost period can be increased up to 4 hours. This will reset back to 15 minutes once you exit boost mode.



Manual temperature mode

In **MANUAL** mode, the heater maintains a chosen set temperature between 15°C and 35°C. To amend the set temperature when in **MANUAL** mode, activate the display and then press TEMP. Next, use the + and - buttons to change the temperature. Once the temperature is set, you can leave the display to return to the main screen and the settings will be saved.

When the room temperature reaches the set temperature, the heating is disabled.

Frost protection mode

In **FROST PROTECT** mode, the heater maintains a chosen set temperature between 4°C and 15°C. To amend the set temperature when in **FROST PROTECT** mode, activate the display and then press TEMP. Next, use the + and - buttons to change the temperature. Once the temperature is set, you can leave the display to return to the main screen and the settings will be saved.



Auto mode

In this mode, the HHPS01 will follow the week's time / temperature program.

The temperature can be temporarily overridden in **AUTO** mode by simply activating the display and using the + and - buttons to set the new temperature. The new set temperature will be then maintained until the next program step.

Advance mode can be used to advance to the next program. To do this, press PROG whilst in **AUTO** mode. To clear advance mode, press PROG. The program currently active is indicated in the top left of the display.

Information on how to set up the program schedule can be found on pages 7 & 8.



Heat symbol

Every time there is a demand for heat, the display will show the heat icon.



Full heat



Half heat (RX only)

Keys locking

Press and hold TIME and TEMP together for 5 seconds. The display will show the symbol.  Repeat the step to unlock.



Open Window Detection

Ensuring you don't waste energy on heating the outside world, the heater is equipped with optional open / closed window detection. The heater recognises sudden drops in temperature when a window or a door is opened and turns the heating off to save energy. When the window is closed, the heater will automatically detect a temperature rise, and switch itself back on. Once enabled in the setup menu, the open window detection is fully automatic and does not require any human intervention to be activated. When open window detection has been triggered, the heat symbol will flash on/off as shown below.





Setting-up Open Window Detection

The system has been factory set to default time and temperature values. If necessary, all values can be adjusted. When the heating is on, open window detection sensor will automatically switch the heater off when it detects a fall in temperature of 2°C in less than 10 minutes (this temperature can be changed in menu 8 and time in menu 7). If a temperature rise of 2°C in less than 30 seconds is detected, the heater will switch itself back on (this temperature can be changed in menu A and time in menu 9).

Displaying the time/temperature

The HHPS01 can display either the time & day or the room temperature when in one of the 4 standard operating modes.

Press the TIME button to alternate between the two options.



Setting the time and day

To set the time and day, follow the steps below;

Step 1: Press and hold the TIME button for 5 seconds. The minutes will flash. Use the + and - buttons to adjust the minutes.



Step 2: Press the TIME button. The hours will flash. Use the + and - buttons to adjust the hours.




Step 3: Press the TIME button. The day will flash. Use the + and - buttons to change the day. Once set, press the TIME button to return to the main screen.




Setting the automatic program schedule

An example of one day program on HHPS01



Logic diagram for setting program on HHPS01



This section provides an example of how to set the 7-day program for one day. The example will program the timer to maintain 21°C from 08:00 until 16:00. It will maintain 4°C from 16:00 onwards. It does this by setting the programs as follows;

Prog 1 - Set to 08:00 and 21°C

Prog 2 - Set to 16:00 and 4°C

Prog 3, 4, 5, 6 - Set to inactive

The steps to program this are shown below;

Step 1: Press and hold the PROG button. The display below should show with Monday flashing



Step 2: Press the PROG button. Prog 1 in the top left of the display should flash. This represents the program number. Each day has 6 programs.



Step 3: Press the PROG button. The time should flash. Use the + and - buttons to set the time you want the heating to switch on.



Step 4: Press the PROG button. The temperature should flash. Use the + and - buttons to set the temperature you want to maintain.



Step 5: Press the PROG button. Monday should flash again.



Step 6: Press the PROG button. Prog 1 in the top left of the display should flash. Use the + button to increment this to Prog 2. (Note: you can cycle between the different programs using the + and - buttons)




Step 7: Press the PROG button. The time should flash. Use the + and - buttons to select the time you want the heating to switch off.



Step 8: Press the PROG button. The temperature should flash. Use the + and - buttons to select a frost protection temperature.



Step 9: Repeat these steps for programs 3-6 if additional time periods are required. Any programs not being utilized must be deactivated. To do this, simply select the program in question as per step 6 and press the TIME button. The time should change to dashes as shown below. To reactivate the program, simply press the TIME button again.



Automatic program overview

The HHPS01 has a 7-day, 5-day 2-day and a 24 hour timer available. This can be chosen in the setup menu. Up to 6 programming steps are available for each day. In the programming you can set a start time and a temperature for each program.


Basic operation

1. Press and hold PROG for 5 seconds to enter the program setting.
2. The day will be flashing. Use + and - to navigate day, press PROG to select day.
3. PROG 1 will be flashing. Use + and - to navigate program, use PROG to select program.
4. The time will be flashing. To set time, use + and -, press PROG to set the time.
5. The temperature will be flashing. To set temperature, use + and - to change temperature, press PROG to set temperature.

To add another program repeat steps 2-10.

Set program inactive

If you do not require the use of all 6 programs they can be deactivated. When in programming mode select the program you want to make inactive and press the TIME button. To activate the program again, press the TIME button.



Copy day function


If you require the same set of programs throughout the week, a 24 hour timer is available. This will use the same program every day. A 5-day + 2-day timer is also available. This will use the same programs Monday-Friday, and the same programs Saturday and Sunday. These modes are enabled in the setup menu, as explained on page 9.

Alternatively, it is possible to copy a program from one day to another. To do this, follow the steps below;


Step 1: Press and hold PROG for 5 seconds to enter the program setting.



Step 2: Press and hold TIME for 5 seconds to enter the copy day setting.



Step 3: Use the PROG button to select the day to copy the programs from. 1= Monday, 2 = Tuesday and so on.




Step 4: Use the + and - buttons to select the day to copy the programs to.



5 - Set maximum temperature



Step 5: Press the TIME button to copy the programs. The 'TO' will flash to confirm the programs have been copied.



6 - Enable/disable open window detection



Setup menu

1. Press and hold TEMP and MODE together for 5 seconds.
2. The display will enter the setup menu.
3. Use + and - to change a value.
4. Use TIME to scroll between the settings.
5. Use PROG to exit the setup menu

1 - Temperature calibration


The temperature reading is factory calibrated but if for any reason it needs adjusting (better accuracy required, to suit different position in the room etc.), the reading can be recalibrated in 0.5 degree steps.



8 - Temperature drop in open window detection time



3 - Adjust fan speed
(Select models only. Does not apply in manual control mode)



9 - Closed window detection time



4 - Set minimum temperature




A - Temperature rise in closed window detection time




B - Program mode select.

Choose between a 7-day, 5-day 2-day or a 24 hour timer.



C - Select operating mode:

1 = temperature control
2 = manual control




D - Enable/disable SL wireless signal



E - Compatibility modes:

0 = Normal operation



The bracket acts as a holder for the controller. The controller can be removed from the bracket easily to operate as a handheld device. Alternatively, a locking screw can be attached from the bottom of the device to permanently fix the controller to the bracket.



Choosing a position in a room

When using the HHPS01 for temperature control, a suitable position in the room should be chosen. Avoid areas with draught or direct sun. Do not position HHPS01 above or close to the heaters or other heat sources. Damp areas or areas where HHPS01 can be mechanically damaged should also be avoided. Typically 1.2 to 1.5m above floor level.

Installing the controller

The controller can be left free-standing or mounted to the wall in a suitable location.

To mount the controller to the wall, the supplied wall bracket should be used. Install the bracket using the 2 screw holes provided as shown in the image.

Batteries

The HHPS01 is battery powered. Remove the battery cover and insert 2 new high quality alkaline AA batteries.

Warning: Smith's is not responsible for damage due to corrosion. Battery leakage will cause permanent damage.

To help avoid battery leak:

- Replace the batteries annually, even if there is not a low battery warning. Remove failing or flat batteries immediately.
- Always fit new high quality alkaline batteries from the same pack. Never mix new and old batteries, or batteries of different brands or types.
- Never attempt to revive alkaline batteries by heating, crushing or recharging.

Note: The clock has to be reset after replacing the batteries. The program settings will be remembered.

Registering your product

Thank you for purchasing a Smith's product. It has been designed and manufactured to the highest quality standards to ensure it gives you efficient and trouble-free service for many years. We are committed to achieving the highest standards and our faith is supported by a free parts and labour guarantee with every product.

For more information on the warranty period for this product please visit our website smithsep.co.uk/product-registration/

This gives you the peace of mind that in the unlikely event of product failure, we will repair or replace the product completely free of charge providing the product has been installed, used and maintained in accordance with the instructions. Your statutory rights are not affected by this warranty.

It is important to register as soon as possible online at: smithsep.co.uk/product-registration/. This will ensure you will receive prompt and efficient service if your product requires attention within the warranty period. If you do not register your product, you will be required to produce proof of purchase prior to receiving service.

For more details please visit our website:
SmithsEP.co.uk

Disposal

As part of the policy of continuous product improvement, Smith's Environmental Products LTD reserves the right to alter specification without prior notice.

Products with this symbol (crossed out wheelie bin) cannot be disposed as household waste. Old electrical and electronic equipment must be recycled at a facility capable of handling these products and their waste by-products. If you are purchasing replacement equipment your retailer may offer a 'take back' scheme, or will be able to give details of the nearest approved authorised treatment facility. Proper recycling and waste disposal will help conserve resources whilst preventing detrimental effects on our health and the environment.

WEEE Registered Code: WEE/ED0093VW



Approved CQS ISO
9001:2015



ISO 14001

After sales

If you experience any problems with the use of your product, please contact our after-sales office +44 (0) 1245 324560.

For product information, customer services or sales support call us on +44 (0) 1245 324900

For the Republic of Ireland, contact MT Agencies
on 01 864 3363

Sales: sales@SmithsEP.co.uk
General information: info@SmithsEP.co.uk

Smith's Environmental Products Ltd
Blackall Industrial Estate, South Woodham Ferrers,
Chelmsford, Essex CM3 5UW

SmithsEP.co.uk

@SmithsEP_UK

#ThinkSmiths

SCAN HERE TO REGISTER
YOUR PRODUCT





Happy to help

Smith's Environmental Products Ltd is one of the leading manufacturers of heating and cooling products in the UK. We are committed to achieving the highest standards and our faith is supported by a free parts and labour guarantee with every product (see our website for more information). Our customer service is second to none and we are happy to offer any help and guidance that you might need.

Stockists

All products are available nationally from Builders' Merchants, Plumbers' Merchants, Heating Equipment Distributors and Kitchen Equipment Distributors. In the event of difficulty, please contact us or visit our website SmithsEP.co.uk for details of your nearest stockist.

Information and advice

Full technical specifications and list prices are available to download from our website or in hard copy from our office. Also available on our website are price lists, individual product data sheets, installation & user guides, where to buy, who to contact and a media centre.

Alternatively contact our office 9.00am to 5.00pm Monday to Friday.

As part of our commitment to continuous improvement Smith's Environmental Products may change the specifications of its products without prior notification or public announcement. All descriptions, illustrations, drawings and specifications in this publication present only general particulars and shall not form part of any contract. All dimensions are in mm unless otherwise stated. Please visit the website for the most up to date information.

**To view the full product information download the datasheet at:
www.SmithsEP.co.uk**

For product information, customer services or sales support call us on **+44 (0) 1245 324900**

For the Republic of Ireland, contact MT Agencies on 01 864 3363

Sales: sales@SmithsEP.co.uk

General information: info@SmithsEP.co.uk

Smith's Environmental Products Ltd
Blackall Industrial Estate, South Woodham Ferrers,
Chelmsford, Essex CM3 5UW

SmithsEP.co.uk

@SmithsEP_UK

#ThinkSmiths

Issue 001 | 85-0081 | January 2026