

## Quick Setup Guide – SLVT Electric Heater Controller

### Pairing with heaters: (Mains Powered Wireless controller)



In order to pair your appliance with the controller:



**Step 1:** Connect the controller to the power Supply.


For the mains power, connect L and N wires to the connectors marked as L and N

**Step 2:** The controller must be in **OFF** setting (the light segments **off** or **red**)



**Step 3:** Turn the power to the heater **ON**, and within **20 seconds** press and hold the **ON** button on the controller until the **Orange** segments light up in a sequence.

On Button



**Step 4:** After the pairing is finished, the light segments will change to **Green**.

If the pairing was successful the heater should turn on . (This can take up to 5 seconds after pairing)



- If process fail repeat all the steps again



**Step 5:** Press the button to exit pairing and switch OFF

- Please read carefully the Installation and Control Guide included with the product for full control and operation guide.